


- FOR APPLICABLE NOTES AND DRIVEWAY REQUIREMENTS SEE STANDARD 130.
- TO CONSTRUCT A DEPRESSION IN EXISTING CURB AND GUTTER:
 - SAWCUT AND REMOVE FOR THE NECESSARY WIDTH.
 - REMOVE AND RECONSTRUCT TO THE NEAREST JOINT.
- A DRIVEWAY APPROACH MUST BE CONSTRUCTED WITH EACH CURB DEPRESSION.
- SURFACING SHALL BE PORTLAND CEMENT CONCRETE (MINOR CONCRETE) 6" THICK AND HAVE A BROOM FINISH.
- DEPRESSED DRIVEWAY IN A FILL CONDITION NOT ALLOWED OR AS DIRECTED BY THE ENGINEER.



SAN BERNARDINO COUNTY DEPARTMENT OF PUBLIC WORKS

COMMERCIAL DRIVEWAY APPROACH DEPRESSED WITH CURB

BRENDON P. BIGGS, PE DIRECTOR OF PUBLIC WORKS/ROAD COMMISSIONER

129A